


COMPONENTI KIT ANTERIORE	FRONT KIT COMPONENTS	COMPOSANTS KIT ANTERIEURE	COMPONENTES KIT DELANTERO	G.P.L. L.P.G.	METANO C.N.G.
Riduttore	Converter	Vaporisateur	Reductor	LEM/LSE SM2	LME SM2
Commutatore	Petrol start switch	Commutateur	Conmutador	C97-I / C97-IS	
avviamento a benzina		demarrage essence	arranque a gasolina		
Elettrovalvola G.P.L.	LPG solenoid valve	Electrovanne GPL	Electroválvula GLP	EV2	-
Sensore manometro metano	CNG sensor and manometer	Capteur pression Methane	Sensor de GNC y manómetro	-	805i
Miscelatore	Mixer	Melangeur	Mezclador	-	-
Emulatore Staccainiettori	Injectors simulator	Emulateur injecteurs	Simulador de inyectores	N° Pitagora 160	

SCHEMA ELETTRICO - WIRING DIAGRAM - SCHEMA ELECTRIQUE - SCHEMA ELECTRICO
**NOTE**

- Scollegare la batteria prima di effettuare qualsiasi operazione.
 - Saldare le connessioni elettriche.
 - Non utilizzare rubacorrente
- MATERIALE CONSIGLIATO**
- Set tubazioni e raccorderie

NOTES

- Disconnect the battery before working.
 - Soft solder wiring connections.
 - Do not use fast-connections
- OTHER SUGGESTED MATERIAL**
- Pipes and fitting set

NOTES

- Déconnecter la batterie avant d'effectuer n'importe quelle operation.
 - Souder les connexions électriques.
 - Ne pas utiliser de connexions rapides.
- MATERIEL CONSEILLE**
- Kit tuyaux et raccords

NOTAS

- Desconectar la batería antes de efectuar cualquier operación
 - Soldar las conexiones eléctricas
 - No utilizar conexiones rápidas
- MATERIA ADICIONAL ACONSEJADO**
- Set cañerías y racores